

MFJ ENTERPRISES

MFJ-101 24HOUR
SOLID STATE DIGITAL ALARM CLOCK

P.O.BOX 494 MISSISSIPPI STATE, MS 39762
TELEPHONE (601) 323-5869

OPERATION INSTRUCTIONS

TIME SET : To set the clock to the desired time, move the 3-way Alarm/Time/LOCK mode switch to the TIME SET position, and depress the fast or slow switch until the desired time is reached.

ALARM SET : To set the desired alarm time, set the alarm switch to OFF, and then set the Alarm/Time/Lock switch to the ALARM SET position. Then set the desired alarm time by depressing the fast or slow switch until the desired alarm time is reached.

ALARM SWITCH : Set this switch to ON position when alarm time is set and alarm is required. Only one dot will appear on the colon on the display as a visual indication of alarm "ON" position. Return to "OFF" position when alarm is no longer desired.

SNOOZE BUTTON : Located on the top of the clock. Once this button is pressed after the alarm has sounded, it turns the alarm off for 9 minutes before the alarm is activated again. This will continue for 59 minutes after the initial alarm has sounded.

ID TIMER : The snooze function can be used as a 9 minute ID TIMER if desired. Set the timer as follows : 1. Note the time displayed on the clock.

charge to the original owner of this MFJ-101 Digital Clock provided that this clock is returned postage prepaid to MFJ Enterprises, Inc. with a personal check, cashier's check, or money order for $3.50 to cover return postage and handling.

3. This warranty is VOID if this clock is tampered with, improperly serviced, or subjected to misuse, negligence, or accidental damage.
4. The obligation of MFJ Enterprises, Inc. under this warranty is limited to the repair or replacement of the defective unit or any part thereof. Under no circumstances is MFJ Enterprises, Inc. liable for consequential damages to persons or property incurred by the use of this clock.
5. This warranty is given in lieu of any other warranties expressed or implied.
6. MFJ Enterprises, Inc. reserves the right to make changes or improvements in design or manufacture without inccurring any obligation to install such changes within any of the products previously manufactured.
7. Warranty service should be addressed to MFJ Enterprises, Inc., 921-A Louisville Road, Starkville, MS. 39759, USA and should be accompanied by

OPERATION INSTRUCTIONS

TIME SET : To set the clock to the desired time, move the 3-way Alarm/Time/LOCK mode switch to the TIME SET position, and depress the fast or slow switch until the desired time is reached.

ALARM SET : To set the desired alarm time, set the alarm switch to OFF, and then set the Alarm/Time/Lock switch to the ALARM SET position. Then set the desired alarm time by depressing the fast or slow switch until the desired alarm time is reached.

ALARM SWITCH : Set this switch to ON position when alarm time is set and alarm is required. Only one dot will appear on the colon on the display as a visual indication of alarm "ON" position. Return to "OFF" position when alarm is no longer desired.

SNOOZE BUTTON : Located on the top of the clock. Once this button is pressed after the alarm has sounded, it turns the alarm off for 9 minutes before the alarm is activated again. This will continue for 59 minutes after the initial alarm has sounded.

ID TIMER : The snooze function can be used as a 9 minute ID TIMER if desired. Set the timer as follows : 1. Note the time displayed on the clock.

2. Turn alarm switch to "ON". 3. Turn 3-way mode switch to ALARM (the display now shows the alarm set time.) 4. Use the fast and/or the slow set buttons to set the alarm time to the same as the display time noted in Step 1. This will activate the alarm. 5. Stop the alarm by depressing the SNOOZE button. The alarm will repeat 9 minutes after the SNOOZE button is pressed. This will continue for 59 minutes. To extend the alarm cycle, simply repeat Step 1. thru 5.. NOTE : The timer will reset to give a 9 minute ID each time the SNOOZE button is pressed.

LOCK SYSTEM : Switch the 3-way Alarm/Time/Lock mode switch to lock. This prevents accidental time advancement by mistakingly pressing the fast or slow buttons.

POWER INTERRUPT INDICATOR : When power is interrupted and later resumed all numerals will flash on and off. Reset to proper time by following the TIME SET and ALARM SET instructions.

POWER REQUIREMENT : 110 VAC, 50 HZ or 60 HZ. Be sure the 50HZ/60HZ switch is set properly for the power line frequency. NOTE: The MFJ-101 can be used for 220/240 VAC 50HZ by using 220/240 VAC to 110 VAC converter.

LIMITED WARRANTY

MFJ Enterprises, Inc. warrants to the original owner of this MFJ-101 Digital Clock, if purchased from an authorized dealer or directly from MFJ Enterprises, Inc. to be free of defects in material and workmanship for a period of one (1) year from the date of purchase provided that the following terms of this warranty are satisfied.

1. The purchaser must retain his dated proof-of-purchase (bill-of-sale, cancelled check, credit card, or money order receipt, etc.), describing the product to establish the validity of any warranty claim and must submit the original or a machine reproduction of such proof-of-purchase to MFJ Enterprises, Inc. at the time warranty service is requested. MFJ Enterprises, Inc. shall have the discretion to deny warranty service without a dated proof-of-purchase. Any evidence of alteration, erasure, or forgery of proof-of-purchase shall be cause to void any and all warranty terms immediately.
2. MFJ Enterprises, Inc. agrees to repair or replace, at the option of MFJ Enterprises, Inc. without

a letter describing the problem in detail along with a copy of the dated proof-of-purchase and a check or money order for $3.50 to cover return postage and handling.

8. This warranty gives you specific rights, and you may also have other rights which vary from state to state.

PRINTED IN JAPAN